

LOG-IC 360°

**Revolutionize Your Cold Chain** 

# Bluetooth Logger Users Guide

- Temperature
- Temperature + Humidity



switrace.com  $\mid$  +41 91 646 18 74  $\mid$  info@switrace.com

Switrace SA | Via F.Catenazzi 5 | 6850 Mendrisio | Switzerland

## **Table of Contents**



LOG-IC® 360 BT GETTING STARTED	3-5
Identifying Your Logger Type	
Downloading the LOG-IC 360 BT App	
Turning Logger On	
Navigation	
Display Abbreviations	5
DEFAULT SETTINGS AND PRE-CONFIGURED PROFILES	
Edit Profile Defaults	
Application Functionality & Information	6
Deploy A Pre-Configured Profile	7
Deleting A Profile	7
CREATING AND USING A CUSTOM PROFILE	8-11
Creating a Custom Profile	8 - 9
Deploy a Custom Profile	10
Deleting a Custom Profile	
Click To Deploy A Profile To Any Device	
Scan To Deploy A Profile To Any Device	11
CREATING AND LIGING A PROFILE TO A RATCH OR CROUP	10
CREATING AND USING A PROFILE TO A BATCH OR GROUP	
Creating a Batch and Deploying a Profile	
Creating a Group and Deploying a Profile	12
UTILIZING USER MARKS	13
User Marks	
	13
READING THE DISPLAY OF A BLUETOOTH LOGGER	14
Reading the Display	
Reading the Display	14
DATA DOWNLOAD AND HISTORY	15-18
Data Download	
Click to Download	
Scan to Download	
Share the Data	
Batch Download and Sharing	
Group Download and Sharing	
History	
LOGGER MONITORING	19
Stop Monitoring a Logger	19
Turning Logger Off	



# LOG-IC® 360 BT **Getting Started**



### **IDENTIFYING YOUR LOGGER TYPE**

ATI offers two versions of the LOG-IC 360 BT Logger including:

- 1) Temperature only
- 2) Temperature + Relative Humidity

### **DOWNLOADING THE LOG-IC 360 BT APP**

Step 1) Go to apps.americanthermal.com.

**Step 2)** Select the Google Play or App Store based on your device.

Step 3) Select "Open."

Step 4) Download the app.

The LOG-IC 360 icon will appear on your smart device home screen.

### **TURNING LOGGER ON**

A logger is off and inactive when the screen is blank. To turn on the logger, press and hold the Power button of the condition of the logger, press and hold the Power button of the condition of the logger is now on but not actively logging.



# LOG-IC® 360 BT **Getting Started**



### **NAVIGATION**

When opening the LOG-IC 360 BT App, you will be prompted with these options:

### **PROFILE**

### CREATE

Create a custom profile for logging.

### **EDIT**

Edit any existing profile including pre-configured and custom.

### **DEPLOY**

Choose a pre-configured or custom profile to deploy.

#### **DATA**

### DOWNLOAD

See all active LOG-IC 360 BT loggers in range.

### FIXED ASSET

View a list of loggers in range with status and temperature data.


### **HISTORY**

View a list of all LOG-IC BT loggers that have been connected to your smart device.

### **CONFIGURATION**

### SETTINGS

Set default profile settings, adjust App functionality and view the App details.





# LOG-IC® 360 BT **Getting Started**

# LOG-IC 360°

### **NAVIGATION**

### TOGGLE BETWEEN SINGLE AND BATCH/GROUP MODE



SINGLE MODE



BATCH/GROUP

### **UNIVERSAL FUNCTIONS**



**CLICK TO CONNECT** 



**OPEN LOGGER SCANNER** 



**RESTART SCANNER** 

### **BATCH/GROUP FUNCTIONS**



ADD/CREATE GROUP



**DOWNLOAD/DEPLOY** 





SHOW/HIDE LIST

(1)

**SHOW GROUP INFORMATION** 

### **DISPLAY ABBREVIATIONS**


**bP:** Button Press

**AP:** Airplane Mode


So: Soak Mode

rdY: Ready

### SINGLE MODE



### **BATCH/GROUP MODE (SHOW LIST)**



### **BATCH/GROUP MODE (HIDE LIST)**





## **Default Settings and Pre-Configured Profiles**



### EDIT PROFILE DEFAULTS

There are a number of default properties that can easily be adjusted for consistent programming.

Step 1) Select SETTINGS

**Step 2)** Adjust the profile defaults including:

- Start Mode
- Soak Time
- Units of Measure
- Airplane Mode
- Log Interval
- · High Speed Logging
- User Notes
- Circular Buffer
- Stop Monitoring

The selections will now be your default options when creating additional profiles.

### APPLICATION FUNCTIONALITY

The LOG-IC 360 BT App can be customized for your usability.

Step 1) Select SETTINGS

Step 2) Click on each option to adjust settings:

- Vibrate on Connect
- Read Range
- Display Units
- Firmware Notifications
- Legacy Scanning
- Date/Time Display Option
- Graph Simplification

### APPLICATION INFORMATION

You can view the current App and Logger Firmware version within this section.

### **Profile Defaults**

Start Mode: On Deploy

Soak Time: 0 Units: Fahrenheit

Airplane Mode: Disabled Airplane Mode Delay: 0

Log Interval: 1

High Speed Logging: Disabled

User Notes: Disabled Circular Buffer: Disabled

Stop Monitoring Button: Disabled

### **Application Functionality**

Vibrate On Connect: Disabled

Read Range: Long Display Units: Celsius

Firmware Notifications: Enabled Legacy Scanning: Disabled DateTime Display Option: Local Graph Simplification: 80%



# Default Settings and Pre-Configured Profiles



### DEPLOY A PRE-CONFIGURED PROFILE

The LOG-IC 360 BT App includes pre-configured profiles that can be deployed instantly to your BT device.

**Step 1)** Be sure your device is on, reading rdY.

If not, hold the Power button of for 2 seconds.

Step 2) Select DEPLOY

Step 3) Select the profile of your choice.

**Step 4)** The App will begin scanning for BT devices within range that are not currently logging.

Step 5) Select your logger.

- If you are unsure which logger to choose, click and release the Power button
- The background of the correct logger will turn green.
- **Step 6)** If you selected notes in your configuration, you will be prompted to type these notes or scan a QR code for details.
- **Step 7)** The app will read **DEPLOYED SUCCESSFULLY** and the current temperature or "SO" for soak will be displayed on the logger screen.

The device will show as ACTIVE in the Scanner screen of the App.

### **DELETING A PROFILE**

To delete a profile, press and hold on the profile for 2 seconds and select Delete.

To stop a logger or turn it off, see page 18.

<b>〈</b> Deploy Profile	Deploy Profile	<u></u>	f
NAME	TEMPERATURE		RSSI
F223608BFBB9	23.72°C		-57dB
E9C04AC641F5	21.67°C		-69dB



# Creating a Custom Profile for Temperature Devices



# CREATING A CUSTOM PROFILE FOR TEMPERATURE ONLY DEVICES

Step 1) Select

CREATE

**Step 2)** You can then select your parameters:

- Name Profile.
- Set Temperature Alarms.
  - Select the red arrow next to Not Used
  - Select what type of of temperature you'd like to monitor - Instant, Cumulative or Continuous
  - Select whether you want to monitor a temperature above or below a certain threshold
  - Select your temperature threshold
  - Set the humidity option as Not Used
  - Set the time
  - Select the blue OK
- Continue this process for up to 4 alarms.
- Within the Details section, you can set:
  - Start Mode
  - Soak Time
  - Units of Measure
  - Airplane Mode
  - Log Interval
  - High Speed Logging
  - User Notes
  - Circular Buffer Older data will be overwritten with new data once max time is met.
  - Stop Monitoring Button A long, 6-second press of the power button will stop the logger from recording.

<b>く</b> Logic 360 BT	Create Profile	
Profile Name		
Enter Profile Name		
Alarm 1	Alarm 2	
Not Used ▼	Not Used ▼	
Alarm 3	Alarm 4	
Not Used ▼	Not Used ▼	
Details		
Start Mode: On D	Deploy	
Soak Time: 0		
Units: Fahrenheit		
Airplane Mode: Disabled		
Airplane Mode Delay: 0		
Log Interval: 1		
High Speed Logging: Disabled		
User Notes: Disa	bled	
Circular Buffer: D	isabled	
Stop Monitoring Button: Disabled		
Max Run Time: 23 Days 14 Hours 39 Minutes 4 Seconds		



## Creating a Custom Profile for Temp + RH Devices



### CREATING A CUSTOM PROFILE FOR TEMPERATURE + RH DEVICE

Step 1) Select CREATE

**Step 2)** You can then select your parameters:

- Name Profile.
- Set Temperature Alarms.
  - Select the red arrow next to Not Used
  - Select what type of temperature you'd like to monitor - Instant, Cumulative or Continuous
  - Select whether you want to monitor a temperature above or below a certain threshold
  - Select your temperature threshold
  - Set the critical humidity level or Not Used
  - Set the time
  - Select the blue OK
- Continue this process for up to 4 alarms.
- Within the Details section, you can set:
  - Start Mode
  - Soak Time
  - Units of Measure
  - Airplane Mode
  - Log Interval
  - High Speed Logging
  - User Notes
  - Circular Buffer Older data will be overwritten with new data once max time is met.
  - Stop Monitoring Button A long, 6-second press of the power button (b) will stop the logger from recording.

Profile Name				
Enter Profile Name				
Alarm 1	Alarm 2			
Not Used ▼	Not Used ▼			
Alarm 3	Alarm 4			
Not Used ▼	Not Used ▼			
Details				
Start Mode: On Deploy				
Soak Time: 0				
Units: Fahrenheit				
Airplane Mode: Disabled				
Airplane Mode Delay: 0				
Log Interval: 1				
High Speed Logging: Disabled				
User Notes: Disabled				
Circular Buffer: Disabled				
Stop Monitoring Button: Disabled				
Max Run Time: 23 Days 14 Hours 39 Minutes 48 Seconds				

\*High speed logging will allow your logger to move to 1-minute sampling periods automatically after reaching a temperature excursion. This will provide you with detailed data about when the excursions occur.



## Deploy a **Custom Profile**



### **DEPLOY A CUSTOM PROFILE**

Step 1) Select

**DEPLOY** 


- Step 2) Select the custom profile.
- **Step 3)** The App will begin scanning for BT devices within range that are not currently logging.
- Step 4) Select your logger.
  - If you are unsure which logger to choose, click and release the Power button 😃
  - The background of the correct logger will turn green.
- **Step 5)** If you selected notes in your configuration, you will be prompted to type these notes or scan a barcode or QR code for details.
- Step 6) The app will read DEPLOYED SUCCESSFULLY and the current temperature or "SO" for soak will be displayed on the logger screen.

The device will show as ACTIVE in the Scanner screen of the app.

### **DELETING A CUSTOM PROFILE**

To delete a profile, press and hold on the profile for 2 seconds and select Delete.

To stop a logger or turn it off, see page 18.



# Creating and Using a Custom Profile



### CLICK TO DEPLOY A PROFILE TO ANY DEVICE

Step 1) Select DEPLOY

Step 2) Select your Profile.

**Step 3)** Select Click to Connect bottom navigation.

Step 4) Click the Power Button on the logger you wish to activate with the selected profile.

**Step 5)** The App will read **DEPLOYED SUCCESSFULLY** and the current temperature or "SO" for soak will be displayed on the logger screen.

<b>〈</b> Deploy Profile	Deploy Profile	<u></u>	f
NAME	TEMPERATURE		RSSI
F223608BFBB9	23.72°C		-57dB
E9C04AC641F5	21.67°C		-69dB

### SCAN TO DEPLOY A PROFILE TO ANY DEVICE

Step 1) Select DEPLOY

Step 2) Select your Profile.

**Step 3)** Select Open Logger Scanner from the bottom navigation.

**Step 4)** Scan the QR code on the back of the logger you wish to activate with the selected profile.

**Step 5)** The App will read **DEPLOYED SUCCESSFULLY** and the current temperature or "SO" for soak will be displayed on the logger screen.



# **Creating and Using**a Profile To a Batch Or Group



### CREATING A BATCH AND DEPLOYING A PROFILE

You may want to deploy the same profile to a selection of loggers.

- Step 1) Select DEPLOY
- **Step 2)** Select the profile of your choice.
- **Step 3)** The device will begin scanning for BT devices within range that are not currently logging.
- Step 4) Click Batch/Group Mode and begin selecting the loggers you would like to deploy the same profile to. The selected loggers will highlight in blue.
- Step 5) Select Download/Deploy

The selected batch of loggers is now actively logging.

### **CREATING A GROUP AND DEPLOYING A PROFILE**

You may want to maintain a saved batch of loggers, called a group. You can also deploy the same profile to a group of loggers.

- Step 1) Select DEPLOY
- **Step 2)** Select the profile of your choice.
- **Step 3)** The device will begin scanning for BT devices within range that are not currently logging.
- **Step 4)** Click Batch/Group Mode and begin selecting the loggers you would like to deploy the same profile to. The selected loggers will turn blue.
- Step 5) Select Add/Create Group 🕀
- **Step 6)** Select the Group you created to deploy the profile. If you are unable to see your group, select Show/Hide List for the available options.

The selected batch of loggers is now actively logging.



# **LOG-IC 360**

### **USER MARKS**

While the device is running, a user can drop a mark to target a specific time or temperature.

**Step 1)** Hold down the Power button (icon) for 2 seconds and release.

Step 2) "Pt" will appear on the display.


**Step 3)** Following the necessary steps, download the temperature data.

**Step 4)** The marked points will be displayed as blue targets within:

- the device graph

- the PDF report

- the CSV file




## **Reading the Display** of a Bluetooth Logger



### READING THE DISPLAY

- When turned ovofile, the display will read "rdY" or "END."
- When turned on with an active profile deployed, the display will show one of these four options:
  - Current temperature.
  - "SO" for soak.
  - An "X" designating an alarm has been triggered along with current temperature.
  - A check mark showing that none of the alarms have been triggered.



- Minimum temperature reached.
- Maximum temperature reached.
- · Average temperature reached.
- Battery life in percent.









There are 3 ways to download data from an individual device - Standard Data Download, Scan to Download and Click to Download.

### DATA DOWNLOAD

Step 1) Select **DOWNLOAD** 

Step 2) Select your logger

- If you are unsure which logger to choose, click and release the Power button 👩
- The background of the correct logger will turn green.
- If you still have trouble finding your logger, select the refresh button on the top right corner of your App screen.
- For ease of downloading data from multiple loggers, select the camera icon on and scan the QR code on the back of the logger.

You will be supplied with detailed data including:

- Start Date
- Location Mode
- Run Time
- Max Run Time
- Battery Level Soak Time
- Log Interval
- Sample Count
- Status
- Min/Max Temp
- Alarm Settings
- Detailed Graph
- You can zoom in on the detailed graph for extensive temperature data.


### **CLICK TO DOWNLOAD**

Step 1) Select DOWNLOAD

Step 2) Select Click to Connect 🖔 from the bottom navigation.

**Step 4)** Click the Power button on the logger you want to download data from.

The App will connect to the logger and download the temperature and/or humidity data from the device.







### **SCAN TO DOWNLOAD**

Step 1) Select DOWNLOAD

**Step 2)** Select Scan of from the bottom navigation.

**Step 3)** Scan the QR code on the back of the logger.

The App will connect to the logger and download the temperature and/or humidity data from the device.

### SHARE THE DATA

Step 1) Select the icon in the top right of the App screen to share the temperature data via CSV or PDF.

**Step 2)** Using the native share function from your phone, you can message or email the data.





There are 2 ways to download and share data from multiple devices – Batch Download and Sharing or Group Download and Sharing.

### BATCH DOWNLOAD AND SHARING

- Step 1) Select DOWNLOAD
- **Step 2)** The device will begin scanning for BT devices within range that are not currently logging.
- **Step 3)** Click Batch/Group Mode and begin selecting the loggers you would like to download data from. The selected loggers will turn blue.
- Step 4) Select Download/Deploy . You will be prompted to either download and stop monitoring or download only.
- **Step 5)** Data will begin downloading. Download complete will appear when finished with a Zip file including the temperature data.
- **Step 6)** Select the Zip file icon to send along to key stakeholders.





### **GROUP DOWNLOAD AND SHARING**

Group downloading provides the ability to pull temperature data for a saved selection of loggers.

- Step 1) Select DOWNLOAD
- **Step 2)** The device will begin scanning for BT devices within range that are not currently logging.
- Step 3) Click Batch/Group Mode and begin selecting the loggers you would like to deploy a profile to. The selected loggers will turn blue.
- **Step 4)** Select Add/Create Group ①
- Step 5) Select the Group you created to download data for. If you are unable to see your group, select Show/Hide List for the full list available.

  The data from the selected batch of loggers will now begin to download.
- **Step 6)** Select the Zip file icon to send along to key stakeholders.

### **HISTORY**

The LOG-IC 360 BT App stores temperature and humidity data for any logger that has been scanned with your device.

- Step 1) Select HISTORY
- Step 2) Select your logger.

All temperature and/or humidity data along with a detailed graph, is included.

- You may see a logger listed multiple times if it has been used more than once. Select the logger with the correct start date and time.



## **Logger Monitoring**



### STOP LOGGING

A logger can be stopped at any time using the LOG-IC 360 BT App.

A logger can be stopped and turned off manually if the Stop Monitoring Button feature within the deployed profile is enabled.

### STOPPING THE LOGGER WITH THE APP

Step 1) Select DOWNLOAD

Step 2) Select your logger.

- If you are unsure which logger to choose, click and release the Power button 💍
- The background of the correct logger will turn green.
- If you still have trouble finding your logger, select the refresh button on the top right corner of your App screen.
- **Step 3)** Once the logger is chosen, scroll to the bottom of the logger detail screen.

**Step 4)** Select Stop Monitoring.

The device will connect and stop the logger. Your logger will now read "End" on the LCD screen.

**Step 5)** Hold the Power button odown for another 2 seconds and the display will turn off.

Your logger is now stopped and turned off.

### STOP THE LOGGER MANUALLY

The Stop Monitoring Button feature within the deployed profile must be enabled to use this functionality.

- **Step 1)** Hold the Power button **(b)** down for 8 seconds.
- Step 2) The display will show "End".
- **Step 3)** Hold the Power button Odown for another 2 seconds and the display will turn off.

Your logger is now stopped and turned off.



### **FCC STATEMENT:**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

The user is cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **RSS 210 WARNING STATEMENT:**

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.





The internal battery is not replaceable. Disposal of a battery into fire or a hot oven, leaving the battery in high temperature surrounding environment or mechanically crushing or cutting a battery can result in an explosion or leakage of flammable liquid or gas. Do not ingest battery, Chemical burn Hazard. This product contains a coin cell battery. If the coin cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death. Keep new and used batteries away from children. If the battery compartment does not close securely stop using the product and keep away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

